

# Walter - WiFi/BLE/NB-IoT/LTE-M module Preliminary Datasheet

### 1 General information

Walter is an ESP32-S3 based IoT board that offers WiFi, Bluetooth 5 (LE), cellular CAT M1/NB1/NB2 and GNSS connectivity.

### 2 Features

Walter is based on an ESP32-S3-WROOM-1-N16R2 module with an on-board Sequans GM02SP modem. This combination makes Walter a unique development board that offers a rich feature-set which include but is not limited to:

- CPU: Xtensa Dual-core 32-bit LX7 CPU (ESP32-S3 SoC)
- RAM: 2MB (Quad SPI) PSRAM
- Flash: 16MB (Quad SPI) Flash memory
- WiFi: 150Mbps(n) 802.11 WiFi b/g/n with on-board antenna
- LTE: CAT M1/NB1/NB2 (GM02SP module)
- GPS: GPS, GNSS Constellation support (GM02SP module)
- Bluetooth: 2Mbps Bluetooth 5 (LE), Bluetooth Mesh
- 24 physical GPIO pins

## 3 Absolute maximum ratings

For the most reliable use and stability of the module we advice to use the typical ratings. We do not guarantee the correct functioning of the device outsite the minimum and maxium range of the module.

Parameter	Units	Minimum rating	Typical rating	Maxium rating
DC Supply Voltage	V	3.0	5.0	5.5
Digital I/O Voltage	V	2.64	3.3	3.6

QuickSpot - 2023

# 4 Interfaces

Walter provides a total of 28 physical pins (3 power, 1 strapping and 24 IO) to interface with external parts. This chapter provides information about these pins as well as internally connected pins and the testpoints located at the bottom of the board.

Power supply pins and their details are available in section 5.1 about the power characteristics.

For more information about specific pins regarding the ESP32-S3 Wroom module or the Sequans GM02SP module, please refer to the datasheet of the corresponding module.

### 4.1 Pin Assignment




Figure 1: Walter Board Pin Assigment

### 4.1.1 External Pins

Table 1 contains the description of the physical pins on Walter available on the underside of the board. The order of this table, in reference to the board, is top to bottom and left to right.

Pin	ESP pin	Input/Output	Description	
VIN	N/A	power input	DC Power Input (Characteristics 5.1)	
GND	N/A	power input	GND Connection	
3V3 SWITCHED	N/A	power output	Switchable $+3.3$ VDC output (Characteristics $5.1$ )	
10	IO10	bidirectional	General purpose I/O	
9	IO9	bidirectional	General purpose I/O	
8	IO8	bidirectional	General purpose I/O	
18	IO18	bidirectional	General purpose I/O	
17	IO17	bidirectional	General purpose I/O	
16	IO16	bidirectional	General purpose I/O	
15	IO15	bidirectional	General purpose I/O	
7	107	bidirectional	General purpose I/O	
6	IO6	bidirectional	General purpose I/O	
5	IO5	bidirectional	General purpose I/O	
4	104	bidirectional	General purpose I/O	
EN	RESET	input	ESP32 reset with 10k pullup	
RX0	RXD0	bidirectional	ESP32 UART0 Receive	
TX0	TXD0	bidirectional	ESP32 UART0 Transmit	
0/3V3_EN	IO0	bidirectional	Bootloader and 3.3VDC switch after boot	
12	IO12	bidirectional	General purpose I/O	
11	IO11	bidirectional	General purpose I/O	
13	IO13	bidirectional	General purpose I/O	
38	IO38	bidirectional	General purpose I/O	
39	IO39	bidirectional	General purpose I/O	
40	IO40	bidirectional	General purpose I/O	
41	IO41	bidirectional	General purpose I/O	
42	1042	bidirectional	General purpose I/O	
2	IO2	bidirectional	General purpose I/O	
1	IO1	bidirectional	General purpose I/O	

Table 1: Walter External Pin Definitions

### 4.1.2 Internal Pins

Table 2 contains the pin descriptions of the internally connected GPIO pins on Walter. These are necessary for either communication between components on the board or reserved for other purposes and thus not available for external use.

ESP pin	Description		
IO19	USB D-		
IO20	USB D+		
IO46	LTE_WAKE0		
IO45	LTE_UART0_TX (See 4.2)		
IO14	LTE_UART0_RX (See 4.2)		
IO21	LTE_UART0_RTS (See 4.2)		
1047	LTE_UART0_CTS (See 4.2)		
IO48	LTE_RESET		

Table 2: Walter Internal Pin Definitions

QuickSpot - 2023

### 4.1.3 Testpoints

Walter contains 23 testpoints on the bottom of the board that serve multiple purposes. You can use these pins for debugging, interfacing and/or flashing of the Sequans GM02SP and the ESP32-S3-WROOM Modules.




Figure 2: Walter Testpoints Layout

Table 3 contains the description of the testpoints as depicted in Figure 2.

Number	Description
1	LTE_JTAG_TRSTN
2	LTE_JTAG_TCK
3	LTE_JTAG_TDO
4	LTE_UART2_RTS
5	LTE_UART2_CTS
6	LTE_PS_STATUS
7	LTE_JTAG_TDI
8	LTE_JTAG_TMS
9	LTE_UART2_RX
10	LTE_UART1_RX
11	LTE_UART1_TX
12	LTE_UART0_TX (Connected to ESP32 GPIO45)
13	LTE_UART0_RX (Connected to ESP32 GPIO14)
14	LTE_UART2_TX
15	LTE_UART1_RTS (Pull-up R4 not fitted)
16	LTE_UART1_CTS (Pull-up R6 not fitted)
17	LTE_UARTO_RTS (100k pull-up)
18	LTE_UART0_CTS (100k pull-up)

Number	Description		
19	ESP_GPIO3 (Strapping pin)		
20	GND		
21	+1.8VDC REF from GM02SP		
22	+3.3VDC		
23	VBUS		

Table 3: Walter Testpoints Description

#### **4.1.4** Others

Not all pins of the ESP32-S3 and Sequans GM02SP on Walter are internally connected, available through physical pins or testpoints. These pins are either reserved for use by the component itself or deemed not necessary to be available externally.

#### 4.2 LTE UART

The Sequans GM02SP module has 3 UART interfaces available by default. Only UART0 is connected to the ESP32-S3 Wroom Module on Walter as shown in Table 2. Communication between modules is possible with AT-commands. Please refer to the corresponding AT Command reference manual of the Sequans GM02SP for all possible AT-commands.

### 5 Electrical and RF Characteristics

#### 5.1 Power

#### 5.1.1 Power Input

Walter can be powered either by connecting a USB-C cable (see USB\_SECTION\_HERE) or via the VIN pin (see pinout 4.1.1).

**DO NOT** power Walter with both the USB-C connection and the VIN-pin! This can lead to seriously damaging the board and external peripherals connected to it!

#### 5.1.2 Power Output

Walter contains a Texas Instruments LM3281YFQR DC-DC Converter which takes power from either the USB-C port or the VIN-pin and converts it to a regulated +3.3VDC supply.

#### 5.1.3 Power Consumption

#### 5.2 **GPIO**

All GPIO pins exposed via the physical pin headers on Walter are 3.3V resistant. If you want to connect 5V or other forms of logic, please use a suitable logic level converter or voltage divider.

Please reference the corresponding datasheets for all minimum, maximum and typical ratings of I/O pins of the ESP32-S3-WROOM or Sequans GM02SP Modules that may or may not be exposed on the Walter Development Board.

#### 5.3 RF

# 6 Mechanical information




Figure 3: Mechanical Drawing Front and Rear View - Unit in mm

### 7 Software

Walter comes without firmware out of the box. You can easily program and upload your own firmware for Walter using MicroPython, Arduino, ESP-IDF... Please refer to the "Getting Started with Walter" available on our GitHub to get you up and running fast.

# 8 Operating conditions

The module can operate in a wide range of temperatures and conditions. The following are guidelines in which the module is guaranteed to work correctly.

Parameter	Units	Minimum rating	Typical rating	Maxium rating
Working temperature	°C	-40		85
Storage temperature	°C	-40		100
Humidity	%RH	10		90
Storage humidity	%RH	5		90

Please note that no condensation may occur on the PCB and components.

# 9 Legal information

This module is distributed worldwide by DPTechnics bv. We are not responsible for any product this module is part of. This datasheet is made with great care for detail but it can be possible the datasheet will be updated with more accurate data in te future. Users of DPTechnics bv products can contact us by letter, telephone or email.

DPTechnics bv Westkapellestraat 396/44 8300 Knokke-Heist Belgium

Tel: +32(0)50 62 13 79 email: info@quickspot.io

web: https://www.quickspot.io